Quick Start

htc one x

Getting to Know Your Phone

For more information, visit **att.com/DeviceSupport**

Setting up Your Phone

Insert the SIM card

① To eject the SIM card tray, insert a small bent paperclip or the SIM eject pin into the small hole next to the tray. You should insert it at an angle.



② Pull the SIM card tray out, and place the SIM card into the tray.



③ Insert the SIM card tray into its slot.

Charge the phone

① Connect the USB cable to your phone.

② Plug in the power adapter to an electrical outlet to start charging.

Important: Please use the power adapter and USB cable that came in the box for optimum battery performance.

Phone Basics

Turn on your phone

Press and hold the power button on the top panel.

Setup wizard

The first time you turn on your phone, you'll be guided to transfer contacts, set up your email and social network accounts, and more.

Be sure to sign in to your Google™ Account to use Google apps such as Gmail™ and Play Store™ on your phone.

AT&T Ready2Go

AT&T Ready2Go helps you set up your new device using the browser on your computer.

① From the Home screen, tap **> AT&T Ready2Go**.

② Tap **Get Started**. You'll see a URL and code.

③ On your computer's browser, go to the web page.

④ Enter your information and choose the setup you want.

⑤ Save your profile to update your device.

Lock and unlock the screen

To lock, briefly press the power button.

To unlock, press the power button, then drag the ring up.

Touch Screen and Navigation

Navigate your phone

- Use your fingertip to lightly tap the screen and select options.
- Use quick flicks of your finger to scroll up/down and left/right.
- **All Apps Key:** Opens a screen to all of your applications.
- **Back Key:** Returns to previous screen.
- **Home Key:** Takes you to the main Home screen.
- **Recent apps Key:** Shows you apps you've recently used.
- **Notification bar:** Shows you timely information, like new message and Facebook notifications, missed calls, and calendar reminders. Touch the bar and slide it down with your finger to see full details. Tap the **Back** key to close the bar.

Slide your finger horizontally to the left or right and you'll discover more space for adding icons, widgets, and more.

Find More Information

Find Accessories

Accessories for your smartphone are available at **att.com/WirelessAccessories** or visit your local AT&T store.

On the Web

- Interactive web tutorials are available at **att.com/Tutorials**. Select Manufacturer: **HTC** and Model: **One X** from the drop down menus.
- Detailed support information is available at **att.com/DeviceSupport**.
- For information about your wireless account or network, visit **att.com/Wireless**.

On the Phone

Call AT&T Customer Care at 1-800-331-0500 or dial 611 from any AT&T mobile phone.

©2012 AT&T Intellectual Property. All rights reserved. All other marks contained herein are property of their respective owners.

Accessories sold separately.

Printed in Taiwan

Personalization

Customize your phone

Customize your phone with wallpapers, widgets, app shortcuts and ringtones.

① Slide the Notifications panel open, and then tap ⚙ > **Personalize** to access customization options.

② Choose what you want to change, such as display or sound preferences.

③ Select from the options, and then tap **Apply**.

Manage Home Screens

You have up to seven Home screens that you can add widgets and shortcuts on.

To add a Home screen item, slide the Notifications panel open, and then tap ⚙ > **Personalize** > **Home screen.** Choose a widget or a shortcut.

To move or remove Home screen items, press and hold and then drag as needed.



Call and Voicemail

Make a phone call

① On the Home screen, tap .

② Enter a phone number or tap a contact from the list.

③ Tap **Call**.

④ To hang up, tap **End call**.

Check your voicemail messages

① On the Home screen, tap .

② Press and hold the number 1 key on the keypad.

③ Enter your passcode, if you use one.

④ Follow the voice prompts.

Text Messaging

Send a text message

① From the Home screen, tap > **Messages**.

② Tap + to compose a new message.

③ Enter a number or tap to browse your contacts.

④ Tap the **Add text** field and then enter your message.

⑤ Tap **Send**, or press to save the message as a draft.

Attach a picture or video

① While composing a text message, tap .

② Tap **Picture** or **Video**.

③ Tap **Gallery** to choose a picture or video from an album, and then tap an item to attach it.

④ Tap **Send**.

Please don't text and drive.

Pay per use charges apply unless you have a Messaging Plan.

Network Notifications

Your 4G LTE wireless device will indicate which of AT&T's wireless networks you are connected to. A network indicator does not necessarily mean that you will experience any particular upload or download data speeds.

Connected to AT&T's 4G LTE network.

* Connected to AT&T's HSPA+ network. AT&T's HSPA+ network is capable of delivering 4G speeds when combined with enhanced backhaul. 4G availability is increasing with ongoing backhaul deployment.

Connected to AT&T's EDGE/2G network.

Actual data upload and download speeds depend on various factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at: wireless.att.com/learn/articles-resources/wireless-terms.jsp, your AT&T Wireless Customer Agreement, Section 3.2 Where and How Does AT&T Service Work?

* AT&T's HSPA+ network can deliver 4G speeds when combined with enhanced backhaul. Your wireless device can't distinguish between HSPA+ cell sites with enhanced backhaul and those without. Enhanced backhaul not available everywhere. Learn more at att.com/network.

Internet

Browse the Web



① From the Home screen, tap > **Internet**.
② Use your fingers to pinch or spread the screen to zoom in and out.
③ To visit another website, tap the address bar, enter the web address, and then tap ▶.
④ To close the web page, tap ✕.

Internet Options

Tap ⋮ to view options:

- **Forward** – Go forward to most recent webpage.
- **Add to** – Create a bookmark or Home screen shortcut for the current webpage, or add the webpage to your Reading list.
- **Bookmarks** – View bookmarks and see your browsing history and most-visited sites list.
- **Tabs** – Show all open browser windows. To open additional browser windows, tap **New tab**.
- **Share page** – Share the webpage you're reading via social networks, email, and more.

Email

If you signed in to your Google Account when you first set up your phone, you'll be able to send and receive Gmail messages. From the Home screen, just tap > **Gmail**.

Set up email

① From the Home screen, tap > **Mail**.
② Choose the type of email account to set up.
③ Enter the **Email address** and **Password** for your email account.
④ Follow the onscreen instructions to complete setup.

Send an email

① From the Home screen, tap > **Mail**.
② Select the email account that you want to use.
③ On the email account inbox, tap +.
④ Fill in one or more recipients.
⑤ Enter the subject and your message.
⑥ To add an attachment, tap **Attach**.
⑦ Tap **Send**, or to send it later, tap **Save**.

Camera

Take a picture

① From the Home screen, tap > **Camera**.
② To zoom in and out, slide your finger on the zoom bar.
③ Tap to take the picture.

Record a video

① From the Home screen, tap > **Camera**.
② Tap to start recording video.
③ Slide your finger on the zoom bar to zoom in and out while recording.
④ Tap to stop recording.

Send a picture or video

① From the Home screen, tap > **Gallery**.
② Browse an album, and then tap a picture or a video.
③ Tap **Share** to share via Bluetooth™, send by email, send as a message, or upload to a social network.

You'll find the following controls on the Viewfinder screen:

	Camera effects
	Camera shutter
	Video recorder
	Gallery shortcut
	Camera scenes
	Camera settings
	Flash level

Music

HTC Sync Manager



HTC Sync Manager lets you organize music and other media files on your computer, and syncs media files with your device.

① Connect your phone to your computer using the supplied USB cable.
② On the Choose a connection type screen, select **HTC Sync Manager**, and then tap **Done**.
③ Download the HTC Sync Manager installer from the HTC website to your computer to start.

Listen to music

① From the Home screen, tap > **Music** > **My phone**.
② Tap ▼ to browse a category, such as **Artists** or **Albums**.
③ While browsing your music collection, tap a song to play it.
④ Tap the onscreen icons to control music playback, repeat songs, and more.

HTC Media Link HD

Enjoy high quality movies from HTC Watch, videos and photos from your own personal collection, YouTube videos and more from the Internet, and project it to wherever a high definition display is available.

Simply connect your device to your home network using HTC Media Link HD and instantly share media on DLNA® compliant devices.

The HTC Media Link HD accessory is sold separately.

AT&T Services

Featured services

The following services are available for your HTC One X:

- **AT&T Code Scanner:** Reads UPC, QR and Data Matrix barcodes. Scan, Shop, Save.
- **AT&T FamilyMap:** Use this subscription service to easily locate a family member's wireless phone on a map from your device. To sign up for this service, visit att.com/familymap.
- **AT&T Navigator℠:** Get traffic updates, GPS navigation and turn-by-turn voice directions.
- **Live TV:** Watch LIVE, on-demand and downloadable mobile TV including ESPN Mobile TV, Fox News and more.
- **myAT&T:** Access billing, usage and feature information as well as manage your account from the palm of your hand.
- **YPmobile:** Use text or voice search to find businesses and events near your location.

Some services may require a separate subscription and incur data usage. AT&T U-verse Live TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection and is available for viewing for limited time periods.

Bluetooth®, Wi-Fi® and Mobile Hotspot

Pair with another Bluetooth device

1. Slide the Notifications panel open, and then tap ⚙.
2. Under **Wireless & networks**, tap the Bluetooth **On/Off** option to turn on.
3. Tap **Bluetooth**, and then tap ⋮ > **Search for devices**.
4. Tap the device name you want to connect to.

Connect to a Wi-Fi network

1. Slide the Notifications panel open, and then tap ⚙.
2. Under **Wireless & networks**, tap the Wi-Fi **On/Off** option to turn on.
3. Tap **Wi-Fi**, and then choose a Wi-Fi network to connect to (secured networks require a passkey).

Share your connection (Tethering and Mobile Hotspot)*

- To use tethering, attach the device you want to tether to your phone with a USB cable. When prompted for the connection type, tap **USB Tethering**.
- To enable a portable hotspot, slide the Notifications panel open, and then tap ⚙. Under **Wireless & networks**, tap **More > Portable hotspot & tethering**. Select **Portable Wi-Fi hotspot** to turn on. Set a password upon first use.

*Requires a minimum of DataPro 5GB plan.

Google Play Store™

Google Play Store is the place to go to find a variety of free and paid apps and more for your phone.

Find and install an app

1. From the Home screen, tap ⋮⋮⋮ **> Play Store**.
2. Browse by featured apps or by category, or search for the app you want.
3. Tap the app to select it.
4. To download or purchase, tap **Download** (for free apps) or the price button (for paid apps).
5. If you agree to the conditions, tap **Accept & download** or **Accept & buy.**

A Google Wallet payment method is required to purchase a paid app. You need to associate a valid credit card or debit card to your Google Wallet account to purchase a paid app.

Calendar

Use the Calendar app to schedule your events, meetings, and appointments. Sign in to your Google, Microsoft Exchange ActiveSync®, or Facebook accounts to see your calendars from these accounts.



Access your calendar

1. From the Home screen, tap ⋮⋮⋮ **> Calendar**.
2. Switch between different calendar views by tapping the bottom tabs.

Set a new appointment

1. On any Calendar view, tap +.
2. If you have more than one calendar, select the calendar in which to add the event.
3. To invite people to your event, tap 👤 and then choose from your contacts.
4. Enter the event details, such as the date and time.
5. Tap **Save**.

Contacts

The Contacts app combines your contacts from accounts like Google, Facebook and Exchange ActiveSync. You can manually add contacts as well.



Add a new contact

1. From the Home screen, tap ⋮⋮⋮ **> Contacts**.
2. Tap + to add a new contact.
3. In the **Name** field, enter the contact name.
4. Select the Contact type, for example Google.
5. Enter the contact information.
6. Tap **Save**.